

ASSEMBLY INSTRUCTION / CHANGING THE INNER SHADE ON A PEDRERA H2O PENDANT



1. Make a fold on the inner shade and lift it out of the lamp.



2. Fold the new inner shade with the adhesive tape pointing inward.




3. Put the new shade inside the old shade.




4. Holding the two shades firmly, use the old shade as a template and make the three cutouts in the top as well as the bottom with scissors.

ASSEMBLY INSTRUCTION / CHANGING THE INNER SHADE ON A PEDRERA H2O PENDANT



5. The inner shade is now ready to be inserted in the lamp with the adhesive tape pointing inward



6. Make sure the inner shade is held firmly against the metal and that it fits well.



7. Make sure it fits in both ends.



8. Carefully remove the yellow protection strip and press the overlap together. This last operation is delicate, so be careful!